




XKELEX Standard Installation Guidelines

ARCHITECTURAL PANELS



AFC-XKELEX Z19
Aluminum Profiles with Rivets

+ RAINSCREEN APPLICATION
8 MM PANELS




These guidelines represent an abbreviated illustration for proper installation of AFC product lines in a ventilated rain screen application. Additional guidelines for interior applications, hidden adhesive attachment, sealing, and weather barrier attachment can be found at americanfibercement.com.


Note: The online copy of the Installation Guidelines obtained at americanfibercement.com supersedes any printed copy.

Construction Practices

1. Air space at top and bottom of building or wall termination to be 25 mm (1") to facilitate airflow from out behind the panels. Do not block vertical airflow at windows, doors, eaves, or at the base of the building. Airflow needs to be continuous from bottom to top so there is air movement behind each panel. See item 4 under Building/Structure on page 5 for proper profile depth based on wall height. 1" is required for walls between 15ft and 60ft. Vertical airflow behind the fiber cement panels is a critical necessity in rainscreen constructions.
2. For areas that receive moderate to high snowfall, panels must terminate 6 to 12 inches above grade line based on expected snow build-up.
3. A metal drip edge may be used at window heads, door heads, and the panel base, but it must not restrict airflow ($\frac{3}{4}$ "; 1" at base openings).
4. Joint closures can be installed (maximum thickness of finishing profile to be .8 mm or 21 gauge). Standard practice is to leave the joints open. If the joints are closed, the base and parapet openings must be increased to a minimum of $1\frac{1}{2}$ ". Backside of panel must remain open to the air cavity. Consult AFC for more information.
5. AFC recommends installing panels from top of building to bottom.
6. For walls with inside corners, start installation there and work across wall.
7. Jobsite Storage (See AFC Storage Guidelines):
 - Keep material laying flat, under cover, dry and protected with a waterproof tarp.
 - Transport material on edge.
 - Using a microfiber cloth, brush off any material dust generated by drilling or cutting prior to installation.
 - Do not use the shipping crates or pallets containing the fiber cement panels as a work surface. Keep panels dust-free.
8. For field cuts and drilling, use carbide or diamond blades/bits and slower turning/feed rates. AFC offers saw blades and drill bits.
9. See AFC's Fabrication, Maintenance, and Storage guidelines.




L or C-Shaped panels are not allowed.




Panels exposed to weather (rain, sun) may only be assembled vertically. Soffit applications not exposed to weather are allowed.

Rainscreen Cladding




Preventing Thermal Bridges

As the insulating material is on the outside of the structural wall, it can easily be mounted without interruptions caused by floor slabs. In this way, any thermal bridges that occur at each floor slab can be prevented. These thermal bridges are also the cause of surface condensation that may result in fungus growth.




Dissipating Heat From the Sun

The ventilated rainscreen cladding system has a cooling effect when temperatures outside are high. Most of the sun's rays are reflected away from the building. Heat passing through the exterior wall panel is partially dissipated by the ventilating effect of the air space between the exterior cladding panel and the structural wall. Any residual heat managing to penetrate buildings is very minor.




Rainscreen

Architectural wall cladding panels act as a rainscreen on the outside of the building and keep the structural wall absolutely dry. The air space connected to the outside air evacuates water and humidity that might have penetrated behind the wall cladding panels through its horizontal or vertical joints. This water will never reach the load-bearing wall and/or the thermal insulation.



Protecting the Basic Structure and Load Bearing Wall Against Temperature Variations

In view of the fact that the insulation material is applied to the outside of the building, changes in temperature are very minor compared with those found in conventional constructions where insulation is applied on the interior. This principle works in summer and winter, in both hot and cold climates.



Prevention of Internal Condensation

Insulation material can be applied to the outside of the structural wall because it is protected effectively by the architectural exterior wall panel. Because of differences in vapor pressure and temperature passing through the wall, condensation has been shown to occur close to the ventilated area and not in the structural wall itself. As a result, the ventilating effect is easily sufficient to dry out the thermal insulating material.

Panels exposed to weather (rain, sun) may only be assembled vertically. Soffit applications not exposed to weather are allowed.

1. **Architect / Engineer / Contractor to design and build structurally sound, water-tight exterior wall.**

- Substructure Horizontal Straightness Tolerance: ± 3.0 mm per 2 m (± 0.0625 " per 42")
- Substructure Vertical Straightness Tolerance: ± 0.5 mm per 600 mm (± 0.0625 " per 75")

If the wall is not straight, the profiles should be shimmed to create a flat plane for the panels. Shims should not be used between the profile and the panel.

- Panels must be installed on a flat surface; no bending

2. **Attach profiles to exterior walls. Structural engineer to determine fastening/affixing specification, i.e. quantity and type of attachment and fasteners, based upon exterior**

FIG. A






FIG. B



For short width panels, contact AFC for guidance on hole locations.

FIG. C



Panel Height > 48"

	in.	(mm)
v:	4"	(100)
h:	2" - 4"	(50 - 100)


*Tall Panels

Panel Width > 48"


	in.	(mm)
v:	2" - 4"	(50 - 100)
h:	4"	(100)

*Wide Panels

FIG. E



Fixed Point — cylinder & rivet



Gliding Point — cylinder & rivet

wall construction. Attachment must support 3.2 lbs/ft² (8 mm panel) dead load, plus design wind loads. Fasteners in profile must accommodate thermal expansion/contraction of metal and not interfere with panel application. Shortening the length of the profiles can minimize thermal expansion and contraction. It is also recommended to oversize holes at or near the tops and bottoms of the profiles while having fixed points near the center. This reduces stress in the panels.

3. XKELEX Z-19 Profiles are 6063-T5 aluminum with custom cross-sectional shapes with thicknesses varying from 2–3 mm. Profile depth is $\frac{3}{4}$ ".
4. The Z19 profile is a $\frac{3}{4}$ " depth horizontally oriented profile with perforations. To allow for enough ventilation, the $\frac{1}{4}$ " thermal spacer must be used. For buildings with panel runs greater than 60ft in length vertically, contact your AFC representative. For buildings over 150 feet high, special provisions are required; check with your AFC representative.
5. Two Z19 profiles are used at horizontal joints. The maximum profile length is 10 feet. Panel can be cantilevered $1\frac{1}{2}$ " – 3" over edge profile so vertical joint is open. See Figure C for hole placement requirements. (See FIG. CB)
6. Profiles to be straight, plumb, level and aligned correctly on the building. **The typical application for this system is a wall assembly without exterior insulation. The Z19 panels are fastened through the sheathing and into the studs using A2 SS #12 x 2" screws w/ washers (supplied by AFC). The profiles are spaced max. 24" on center up the wall.** (See FIG. J)
7. **It is recommended to take field measurements before panels are cut or drilled.** Field measurements verify print dimensions to ensure proper fit.
8. Spacing between horizontal profiles to be ≥ 20 mm ($\frac{3}{4}$ "). A joint between the horizontal profiles must always coincide with a joint between the panels (FIG. A). The joint is preferably continued at the same horizontal height among adjacent profiles. (Reduces stress in panels).

Note: The XKELEX profiles should only cantilever over the vertical profiles by 6" or less. If farther, a structural engineer must be consulted.
9. For structures with exterior insulation, follow the insulation manufacturer's installation instructions. Vertical metal profiles (the same depth as the exterior insulation) can be attached to the exterior wall. The H19 or Z19 metal profiles are then attached to the vertical profiles.

Prepare Profile

1. Typical vertical and horizontal joints are left open and have a black background (use a black weather and UV resistant building wrap). Metal profiles visible at joint openings (vertical or horizontal) can be covered with a black UV weather resistant tape or UV weather resistant coating. Other reveal colors are possible if desired.
2. Horizontal and vertical joints can be closed with aluminum profiles (21 gauge or less) if desired.

Profile Attachment – ILLUSTRATED

For wall assemblies utilizing exterior sheathing with low screw-holding strength, a two-layer attachment system may be required. (See fig. D-1B)

FIG. D-1A-

Two Z-profiles may be used at a horizontal joint (recommended)





FIG. D-2-

Slots in the profile allow for the drainage of water and circulation of air.




FIG. D-1B-

Building wrap per AFC. Weather and UV resistant. Check local codes for proper placement.





FIG. J

Cross-section showing ventilation and attachment to steel studs.




FIG. H Astro Rivet® with fixed cylinder




FIG. I Centralizing drill bit




For centering pilot hole in profile for Fixed Points and Gliding Points.

Panels

1. Joints between profiles must coincide with horizontal joints in the panels. Panels cannot bridge a break in the profiles. (See **FIG. A**)
2. Vertical and horizontal joints to be 10mm ($\frac{3}{8}$ "). This is the minimum distance between the edges of two adjacent panels, or the distance from panel edge to metal trim extrusions or structural members. (See **FIG. A**)
3. Pre-drill holes in panel. Diameter of the fixed and gliding point holes are all 9.5mm ($\frac{3}{8}$ "). Drill bits supplied by AFC.
4. The pilot hole in metal profile must be in the center of both the fixed point and gliding point holes. Use drill bit centralizing fixture (supplied by AFC) to accomplish this geometry. Pilot hole to be 4.1mm in diameter (bits supplied by AFC). Remove drill shavings from metal profile holes before popping rivets. (See **FIG. I**)
5. Some AFC Fiber Cement Products have a sanding grain that must be accounted for when positioning panels. Rotating some panels 90° from the orientation of adjacent panels can result in the appearance of color shading.

VENTILATED RAINSCREEN APPLICATION


6. Affix the two fixed-point holes first. For the fixed-point holes, the AFC supplied 9.4mm diameter sleeves must be slid onto the rivet before affixing. (See **FIG. H**)
7. Rivets are attached using a rivet gun and must have a nose piece attachment supplied by AFC to prevent the rivet from overtightening the panel to the substrate.



Fixing

1. Rivets to be are to be supplied by AFC with colored or stainless steel head. Shank of rivet is 4.0 x 18mm long, with a 15mm diameter head (See **FIG. H**)
2. Fixing pattern is typically either 16" or 24" (max) on center horizontally (based upon vertical profile spacing) and 16" to 24" (max) on center vertically, depending upon building height, building location, design criteria/specifications, and panel/fastener location on building. Edge areas on facades and high wind load conditions require closer fixing distances. Structural engineer to determine spacings. For soffit applications, the maximum fastener spacing is 16" on center in both directions.
3. Corner rivets to be located at 70-150mm ($2\frac{3}{4}$ " - 6") horizontally and 100 - 150 mm (4" - 6") vertically from every corner of panel. (See **FIG. C**)
4. 10mm ($\frac{3}{8}$ ") clearance is required from the edge of metal profile to pilot hole for rivet.
5. Two fixed points are required per panel. (See **FIG. I & J**) Fixed points (for attachment to vertical profiles) are:
 - Always the same height in each panel.
 - As close to center of panel as possible, and then either the next adjacent point to the left or right. Be consistent in panel-to-panel location (center and left or center and right, so fixed points are at the same level horizontally for attachment to vertical profiles).
 - No two fixed points on one panel can be on the same profile, and no two fixed points on two adjacent panels can be on the same profile when adjacent panels share a profile at a vertical joint.
 - For smaller panel sizes with only two rows of fasteners, fixed points to be top center and top left or top right (horizontal applications on vertical profiles). For vertical narrow panel applications on vertical profiles, vertical joints must incorporate two separate profiles (as illustrated. (See **FIG. K**)

FIG. F - Vertical installation on horizontal profiles




The center column must be centered on the panel.

FIG. G - Horizontal installation on horizontal profiles. When there is an even number of fastener columns as shown, the Fixed points should be diagonal from one another to provide equal weight distribution.



FIG. K - Fixing sequence Attach fixed points first.




For AFC Groove Panels:

1. The same rivet is used with the same holes sizes but the rivet must be placed on the non-grooved portion of the panel. (See FIG. L)

FIG. L

Can be horizontally affixed directly to the studs through the sheathing.




Fabrication/Maintenance/Storage


Panels can be used full size (4' x 8' or 4' x 10'), or fabricated to smaller dimensions.

Typical Pattern Layout


Panels can be used full size (4' x 8' or 4' x 10'), or fabricated to smaller dimensions.



Straight pattern with vertical panels




Straight pattern with horizontal panels




Semi pattern with horizontal panels




Typical Horizontal Panel Joint




Typical Vertical Panel Joint




Typical Panel Base




Typical Inside Corner – Plan View




Typical Panel @ Window Head or Door Head



Typical Outside Corner – Plan View




Typical Panel @ Door Head




Building Height (ft)	Dimension (a)
0–30	1"
30–50	2"
50–80	3"
80+	4"

Typical Panel End @ Metal Panel



Typical Panel @ Window Head



Product Sustainability Statement

AFC is committed to providing the highest quality high-density compressed fiber cement panels to the U.S. and Canadian building markets. In order to do this, we feel it necessary to provide not only high-quality products, but sustainable products that can contribute to green (LEED) building projects, which in turn benefit the environment we all live in. AFC products currently have a potential contribution to various LEED credits including but not limited to:

Direct Contribution

Materials and Resources:

- Environmental Product Declarations
- Material Ingredients
- Building Life-cycle Impact Reduction

Indirect Contribution

Indoor Environmental Quality:

- Thermal Comfort

Energy and Atmosphere:

- Optimize Energy Performance

One of the most important sustainable attributes is the durability of AFC panels. With their long lifespan, virtually requiring no refurbishment, AFC panels can contribute to less replacement of materials and to drastically lower maintenance costs over the useful life of the building.

The Ventilated and Insulated Rainscreen Cladding (VIRSC) system, which is used to affix AFC panels to the exterior of a structure, offers many benefits and green attributes to the performance of the building envelope. Durability and resistance to moisture and mold build-up are noteworthy benefits. Equally important is its ability to accommodate external insulation.

In addition, AFC is dedicated to further research and analysis of our products to achieve additional LEED credits, and help further the cause of building sustainable and efficient buildings.

Warranty information available upon request.

6901 South Pierce Street
Suite 180, Littleton, CO 80128 U.S.A.
Phone: 303.972.5107, 800.688.8677

americanfibercement.com

For the nearest authorized fabricator, call 303.972.5107.

Distributed exclusively by:



Limited Warranty

American Fiber Cement (AFC) warrants that its products are manufactured in accordance with its applicable material specifications and are free from defects in materials and workmanship using AFC's specifications as a standard. Only products which are installed and used in accordance with applicable AFC instructions and specifications are in any way warranted by AFC. For specific warranty information, consult AFC or an AFC representative. If a claim is made, you must allow reasonable investigation of the product you claim is defective and you must supply samples that adequately demonstrate the problem you claim for testing by AFC.

AFC DISCLAIMS ALL IMPLIED WARRANTIES INCLUDING THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE THIS LIMITED WARRANTY PROVIDES YOUR EXCLUSIVE REMEDY AS A PURCHASER OF AFC PRODUCTS. THIS LIMITED WARRANTY MAY BE MODIFIED OR AMENDED ONLY BY A WRITTEN INSTRUMENT SIGNED BY A DULY AUTHORIZED REPRESENTATIVE OF AFC. WITHOUT AN EXPRESS, WRITTEN AUTHORIZATION FROM AFC, NO RETAILER OR DISTRIBUTOR OF AFC PRODUCTS HAS THE AUTHORITY TO MODIFY OR AMEND THIS LIMITED WARRANTY.

Limitation of Liability

This limited warranty is your sole and exclusive remedy. It is expressly understood and agreed that the limit of liability will be, at AFC's option, repair, resupply of a like quantity of non-defective product, or refund of purchase price of the material. All labor and service charges which may be incurred with respect to either the original or replacement product are excluded. AFC shall have no liability except where the claim results solely from breach of AFC's limited warranty.

AFC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. FURTHERMORE, AFC SHALL NOT BE LIABLE FOR DAMAGE TO THE PROPERTY TO WHICH THE PRODUCT IS APPLIED OR ITS CONTENTS, LOSS OF TIME, PROFITS, OR ANY INCONVENIENCE ARISING OUT OF ANY BREACH OF THIS LIMITED WARRANTY OR OBLIGATIONS UNDER THIS LIMITED WARRANTY. AFC SHALL NOT BE LIABLE FOR ANY DAMAGES WHICH ARE BASED UPON NEGLIGENCE, BREACH OF WARRANTY, STRICT LIABILITY, OR ANY OTHER THEORY EXCEPT THE LIMITED WARRANTY SET FORTH ABOVE. INCIDENTAL AND CONSEQUENTIAL DAMAGES SHALL NOT BE RECOVERABLE EVEN IF THE REPLACEMENT REMEDY FAILS OF ITS PURPOSE OR FOR ANY OTHER REASON.

